




INSTALLATION GUIDE








**NOTE: THIS INSTALLATION MANUAL
CAN BE REFERRED FOR ALL UNIRAL
VALVE AUTO CLOSING SYSTEM .**



Requirements:-

- ❖ Teflon Tape, Wrench for fitting & tightening
- ❖ Allen key for screw tightening (Included in box)

* Representative image



How to operate.



Safety Tips & Cleaning instruction.

- ❖ Make sure Pipe is properly aligned with Concealed
- ❖ Make sure no loose fitting:
- ❖ Avoid any leakage during connection.
- ❖ Don't use any metal/hard bristle scrub while cleaning .
- ❖ Use soft water & wipe up with soft cotton cloth



Correct Cleaning Steps:

1. Apply Liquid Soap (pH ~7):

Use a mild liquid soap (pH 5-7) or Glitz solution with a neutral water.

Spray it gently on the Outer surface of Product.

2. Use a Soft Cotton Cloth:

Wipe the Product with a soft cotton cloth to remove dirt, stains, or water marks.

This prevents scratches and keeps the surface shiny.

3. Rinse with Water:

Spray clean water on the fitting after wiping with soap.

This helps remove any soap residue.

4. Final Wipe with Soft Cotton Cloth:

Again, wipe with a soft cotton cloth to dry the fitting.

This ensures no water spots are left.

✗ Don'ts (Avoid These):

Don't use Powder Soap:


It can be abrasive and scratch the fitting surface.

Don't use Scrubbing Pads:

Scrubbing with rough materials can damage the finish and reduce shine.

*** Recommended cleaning:-
Twice in week**

Steps & Cleaning agents requirements for Cleaning.



NOTE: THIS INSTALLATION MANUAL CAN BE REFERRED FOR ALL UNIRAL VALVE AUTO CLOSING SYSTEM .