




### Sink Cock with Regular Swinging Spout (Table Mounted Model)



\* Representative image


### Temp & water pressure Requirement.

|  |                              |
|--|------------------------------|
|  | Working Pressure: 1~3 bar    |
|  | Required Temperature: 5-65°C |


- **Working Pressure:**-The water pressure should be Between 1 and 3 bar for proper functioning.
- **Required Temperature:**- The water temperature within the range of 5-65° for safe & effective use.
- **Note:**- These are recommended values for achieving conventional /Optimum output.

### Guideline for Braided hose Installation

- Keep the hose straight as much as possible.
- Don't twist or bend hose during connection.
- Make sure hose is fully tighten to avoid any leakage.



**Note: THIS INSTALLATION MANUAL CAN BE REFERRED FOR ALL SINK COCK WITH REGULAR SWINGING SPOUT TABLE MOUNTED MODEL.**



**Note: THIS INSTALLATION MANUAL CAN BE REFERRED FOR ALL SINK COCK WITH REGULAR SWINGING SPOUT TABLE MOUNTED MODEL.**



|                                                                                              |                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |                                |
|----------------------------------------------------------------------------------------------|------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| <p><b>LIQUID SOAP PH-5-7</b></p> <p><b>Note:</b> Apply liquid soap pH-B/W 5~7 or Glitz .</p> | <p>Apply soft cotton cloth</p>                 | <p><b>WATER</b></p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | <p>Apply soft cotton cloth</p> |
| <p><b>POWDER SOAP</b></p> <p><b>❌ DON'T</b></p>                                              | <p>Don't apply Scrub</p> <p><b>❌ DON'T</b></p> | <p><u>Steps &amp; Cleaning agents requirements for Cleaning.</u></p> <div style="display: flex; align-items: center; justify-content: space-around;"> <div style="text-align: center;"> <p>Aerator</p> </div> <div style="text-align: center;"> <p>1 hour Dip in De-Scale Water</p> <p>De-Scale Water</p> </div> <div style="text-align: center;"> <p>Liquid Soap PH-5-7</p> </div> <div style="text-align: center;"> <p>For Non-Chrome surfaces</p> </div> <div style="text-align: center;"> <p>For Chrome surfaces</p> </div> </div> <p>Recommended Cleaning:- Twice a week.</p> |                                |

**Note: THIS INSTALLATION MANUAL CAN BE REFERRED FOR ALL SINK COCK WITH REGULAR SWINGING SPOUT TABLE MOUNTED MODEL.**